








► COMMON SHEET\_PRINT

NO	PART NO	ITEM	QTY
1	ABHB0ACP001	CENTER BUTTON COVER ACRYL SHEET	1
2	ABHB0ACP002	LEFT BUTTON COVER ACRYL SHEET	1
3	ABHB0ACP003	RIGHT BUTTON COVER ACRYL SHEET	1
4	ABHB0ACP004	CONTROLLER SIDE ACRYL SHEET L	1
5	ABHB0ACP005	CONTROLLER SIDE ACRYL SHEET R	1
6	ABHB0ACP006	BILLBOARD CENTER ACRYL SHEET	1
7	ABHB0ACP007	BILLBOARD REAR SHEET	1

COMMON SHEET_PRINT			
1	2	3	4
			
			

► COMMON SHEET

A1	MBHB0SHE001	BUTTON TABLE SHEET	1
A2	MBHB0SHE002	FRONT DOOT SHEET L	1
A3	MBHB0SHE003	FRONT DOOT SHEET R	1
A4	MBHB0SHE004	SIDE SHEET L-A	1
A5	MBHB0SHE005	SIDE SHEET L-B	1
A6	MBHB0SHE006	SIDE SHEET R-A	1
A7	MBHB0SHE007	SIDE SHEET R-A	1
A8	MBHB0SHE008	LEFT BUTTON SHEET	1
A9	MBHB0SHE009	RIGHT BUTTON SHEET	1
A10	MBHB0SHE018	CENTER BUTTON SHEET	1
A11	MBHB0SHE019	COIN COVER SHEET	1
A12	MBHB0SHE020	BILL COVER SHEET	1
A13	MBHB0SHE021	SET UP PANEL SHEET	1

COMMON SHEET			
A1	A2	A3	A4
